

SAMMYS® FOR WOOD

SAMMYS® FOR WOOD - Vertical Application



Application

Not less than 2" nominal width (1-1/2")

Not less than 3" nominal thickness (2-1/2") (depth or side of vertical member)

For vertical use - install in center of lower face.

Minimum 2" embedment into base material for NFPA 13 compliance.

Composite / Truss
Consult truss manufacturer for recommended installation point.

*Pre-drilling may be required for GST 25-380. Tool available on page 11.

Product Features

- No pre-drilling required.
- Quick to install using the Sammy Nut Driver with an 18V cordless drill/driver.
- Saves time from traditional methods.
- Reduces installation costs.
- Manufactured in the U.S.A.

Watch a video demonstration at www.itwbuildex.com

Approvals	Rod Size	Part Number	Model	Screw Descriptions	Ultimate Pullout (lbs)	UL Test Load (lbs)	FM Test Load (lbs)	Box Qty	Case Qty
VERTICAL MOUNT									
	1/4"	8002957	GST 100	1/4 x 1"	210 (7/16" OSB) 670 (3/4" Ply)			25	125
	1/4"	8003957	GST 200	1/4 x 2"	1760 (Fir)			25	125
	3/8"	8007957	GST 10	1/4 x 1"	210 (7/16" OSB) 670 (3/4" Ply)	300		25	125
 	3/8"	8008957	GST 20	1/4 x 2"	1760 (Fir)	850	1475	25	125
 	3/8"	8068925	GST 20-SS	1/4 x 2"	1760 (Fir)	850		25	125
 	3/8"	8009925	GST 25-380	3/8 x 2-1/2"	2113 (Fir)	1500		25	125
 	3/8"	8010957	GST 30	1/4 x 3"	2060 (Fir)	1500	1475	25	125
	3/8"	8069925	GST 30-SS	1/4 x 3"	2060 (Fir)			25	125
	1/2"	8013925	GST 2	1/4 x 2"	1760 (Fir)			25	125
	1/2"	8015925	GST 3	1/4 x 3"	2275 (Fir)			25	125



#14 Black Nut Driver
Part # 8113910



#14 SW Red Nut Driver
Part # 8114910



SPECIAL NUT DRIVER SYSTEM: The nut drivers were designed with a unique spin-off feature which provides a fast and safe installation each time. When the face of the driver comes into contact with the material you are installing into, continue drilling until nut driver spins free. Installation is then complete. Warranty requires the use of the appropriate nut driver for installations.